# **Bona Prime Amberseal**

## Technical data sheet

**Bona Prime Amberseal** embellishes wooden floors with a rich, amber wood colouration similar to that of traditional, solventbased varnishes but without the hazards associated. Excellent abradability and short drying time also makes Bona Prime Amberseal easy to use and a natural and safe alternative for your wooden floors.

- Compatible with all Bona's waterborne topcoats
- Rich, amber wood colouration
- Based on a polyurethane dispersion for increased durability
- Excellent abradabillity
- Reduces potential for sidebonding
- NMP and NEP free
- VOC 2010 compliant

#### Technical data

Type of varnish: Tinted 1-component waterborne polyurethane primer

Solids content: ~32% VOC: max 95 g/lit

Dilution: If required, dilute with Bona Retarder (4%) for longer open time.

Drying time: 1-2 hours (20°C/60% R.H)

Application tools: Bona Roller

Application rate: 8-10 m²/lit (120-100g/m²) per coat

Safety: Unclassified

Cleaning: Wipe tools free from residual material before cleaning with a

minimum of water. Dried material can be removed with acetone.

Shelf life: 1 year from date of production in unopened original container
Storage/transport: The temperature must not fall below +5°C or exceed +25°C

during storage or transport

Disposal: Wastes and emptied containers should be handled in accordance

with local regulations.

Pack size: 3 x 5 litres (44 boxes per pallet)

# Preparations

Ensure floor is acclimatised to its end-use environment. The surface which is to be coated must be sanded back to bare wood, dry and free from sanding dust, oil, wax and other contamination. The Bona Scrad system or a Bona Sanding Screen grit 120 should be used for the final sanding of the wood.

Allow product to reach room temperature and shake it well before use. Optimal conditions are between 18-25°C and 40-60% relative air humidity. High temperatures and low humidity shorten drying time, low temperatures and high humidity lengthen the drying time. **Absolute minimum temperature for use is 13°C**.

# Treatment schedule

Untreated wood, domestic floor:

1x Bona Prime Amberseal Light sanding grit 1501x Bona Prime Amberseal

1-2x Bona Waterborne Topcoat

Untreated wood, commercial floor:

1x Bona Prime Amberseal Light sanding grit 150

1x Bona Prime Amberseal

2x Bona Waterborne Topcoat

**Note:** It is not recommended to apply more than two full coats per day due to risk of excessive wood swelling.







# **Bona Prime Amberseal**

# Technical data sheet

# Finishing

## Application

- Using a Bona Roller, apply the primer evenly avoiding accumulation of product. Care should be taken to achieve a uniform level of timber saturation to avoid colour variation. Always maintain a 'wet edge' to avoid overlaps.
- 2. When dry, abrade to reduce grain raise using the Bona Scrad system or a sanding screen grit 150 or finer.
- 3. Remove all dust and apply an additional layer of Bona Amberseal and let dry.
- 4. Apply 1-2 layers of a waterborne topcoat from Bona depending on wear resistance requirements.

## Maintenance

Bona Amberseal should never be used as the final treatment for timber floors.

## Important Notes

The information provided is prepared to the best of our current knowledge but makes no claim to be complete. User is responsible for establishing that the product and recommendations herein are fit for the designated purpose, wood type and present situation before use. Bona can only guarantee the delivered product. A professional and thereby successful application of the product is beyond our control. If in doubt make a preliminary test. User is required to read and understand all information contained on package labels and safety data sheets before using this product.

